

CODE 14

COOLANT TEMPERATURE SENSOR CIRCUIT (HIGH TEMPERATURE INDICATED) 2.8L "P" SERIES (PORT)

Circuit Description:

The coolant temperature sensor uses a thermistor to control the signal voltage to the ECM. The ECM applies a voltage on CKT 410 to the sensor. When the engine is cold the sensor (thermistor) resistance is high, therefore, the ECM will see high signal voltage.

As the engine warms, the sensor resistance becomes less, and the voltage drops. At normal engine operating temperature (85°C to 95°C) the voltage will measure about 1.5 to 2.0 volts.

Test Description: Numbers below refer to circled numbers on the diagnostic chart.

- 1. Code 14 will set if:
 - Signal voltage indicates a coolant temperature above 135°C (275°F) for 3 seconds
 - Engine running longer than 20 seconds
- 2. This test will determine if CKT 410 is shorted to ground which will cause the conditions for Code 14.

Diagnostic Aids:

Check harness routing for a potential short to ground in CKT 410.

"Scan" tool displays engine temp. in degrees centigrade. After engine is started, the temperature should rise steadily to about 90°C then stabilize when thermostat opens.

Refer to "Intermittents" in Section "B".

CODE 14 COOLANT TEMPERATURE SENSOR CIRCUIT (HIGH TEMPERATURE INDICATED) 2.8L "P" SERIES (PORT) DOES "SCAN" DISPLAY 130°C OR HOTTER? NO YES CODE 14 IS INTERMITTENT. IF NO **DISCONNECT SENSOR.** (2) . ADDITIONAL CODES WERE STORED, REFER "SCAN" SHOULD DISPLAY TEMP. BELOW -30°C. TO "DIAGNOSTIC AIDS" ON FACING PAGE. DOES IT? NO YES CKT 410 SHORTED TO GROUND. FAULTY SENSOR. OR CKT 410 SHORTED TO SENSOR GROUND CIRCUIT. OR FAULTY ECM. **DIAGNOSTIC AID COOLANT SENSOR TEMPERATURE TO RESISTANCE VALUES** (APPROXIMATE) °F °C OHMS 210 100 185 70 450 160 100 38 1,800 70 20 3,400 7,500 40 4 -7 13,500 20 -18 25,000 0 -40 -40 100,700

CLEAR CODES AND CONFIRM "CLOSED LOOP" OPERATION AND NO "SERVICE ENGINE SOON" LIGHT.

4-28-87

• 7S 3055-6E